



MOTOROLA

instructions manual revision

GENERAL

This revision details changes that have taken place since the printing of your manual. Use this information to update your manual.

MANUAL AFFECTED

68P02950C60-B, *Mobile Workstation 520™, Owner's Manual*

REVISION DETAILS

Powering Off under Windows NT®

When you start Windows NT 4.0, the *Logon Information* dialog box is displayed on the screen, allowing you to select the required course of action. If the *Shutdown* option is selected, the *Shutdown Computer* dialog box appears on the screen. The following table describes the options and the results if selected.



Option	Results if Selected
Shutdown	All the Windows drivers are shut down and you can turn off the MW-520 when the Backlight LED starts blinking, using the Power button. You can also restart the MW-520 by clicking in <i>Restart</i> button on the <i>Shutdown Computer</i> prompt.
Shutdown and Restart	All the Windows drivers will be shut down and the MW-520 is automatically restarted.
Shutdown and Power off	All the Windows drivers will be shut down and the MW-520 is turned off.

NOTE

For Windows NT to execute this procedure correctly, some 30 seconds must elapse between the time this dialog box appears on the screen and the time this option is selected.

Formatting SRAM Cards in Windows NT®

To format an SRAM/ATA card under Windows NT:

1. Insert the card into its slot.
2. When you get the *Card Configured* dialog box click OK.
3. Run *Disk Administrator* (from *Start/Program Files/Administrative Tools/Disk Administrator*).
4. A prompt for some devices not being ready may appear. Click OK.
5. When the *Disk Administrator* is displayed, select the disk that corresponds to the SRAM card that you have inserted.
6. The following prompt may appear:
No signature on disk 1. Would you like to create signature?
Click YES.
7. Create a partition on this disk by selecting *Create* from the *Partition* menu at the top.

8. Once the partition has been created, select *Commit Changes now* from the *Partition* menu to save the changes and click YES in the displayed prompt.
9. Select the newly created partition and select *Format* from the *Tools* menu.
10. Format the partition as FAT. Do not use NTFS because NTFS FILE SYSTEMS ARE NOT SUPPORTED ON REMOVABLE DRIVES.
11. Assign a drive letter to the newly formatted partition (*Assign Drive Letter* from the *Tools* menu).
12. Exit *Disk Administrator*.
13. Once you do this, *Card Executive* will recognize the partition and automatically assign and remove drive letters when you insert and remove the PC Card. If you seem to lose the partition information when you remove and reinsert the card, please check and make sure that the battery on your SRAM card is okay.